DN15-50 M1F, G1F & H1F

NUMBER 99.22.10-A Date: 08/09-2023



CLORIUS CONTROLS 2-WAY CONTROL VALVES

DN15-50 M1F, G1F & H1F

Instructions for

- Installation
- Commissioning
- Operation and maintenance
- Transport and storage
- Spare parts



mail@cloriuscontrols.com www.cloriuscontrols.com

DN15-50 M1F, G1F & H1F

NUMBER 99.22.10-A Date: 08/09-2023

General safety instructions

The valves must be installed and serviced by fully trained and qualified personnel only, observing the accepted industry codes and practices. Make sure employees or third persons are not exposed to any danger.

Design

The valve components - seat and cone and spindle - are made of stainless steel.

The leakage rate is less than ≤ 0,05% of Kvs

Technical Data

Seat and cone material: Stainless steel (W. No. 1.4305)
 Spindle material: Stainless steel (W. No. 1.4305)

Colour: RAL7016

Installation


It is recommended to use a strainer in front of the control valve if the liquid contains suspended particles.

A cooling unit must be applied corresponding to the actuators temperature limitations.

Up to 170°C the valve can be installed vertically as well as horizontally. For media temperature above 170°C it must then be installed with electric actuator/ thermostat downwards.

Comissioning

Manual adjusting device



The device has a built-in stuffing box. For tightening and manual operation of valves when an actuator has not been fitted, e.g. during periods of construction (max. 170°C).

1 of 6



DN15-50 M1F, G1F & H1F

NUMBER 99.22.10-A Date: 08/09-2023

Flow directional marking

The valve is marked with an arrow indicating the correct flow direction of the media. The arrow is located on the attached valve label.

Operation

Without an actuator being installed, the valve is completely open by means of a spring.

By increasing pressure on the spindle, the internal cone will close the valve.

In connection with our thermostats or electric actuators, the valves will close at rising temperatures.

Maintenance schedule – age management.

The gaskets have a durability of approximately 8 years at continuous use. However, it is recommended that the gaskets are inspected and changed every 4 years if possible.

Maintenance: disassembly actuator from the valve:


a. Follow the separate instructions manual according to the actuator type which is installed on the valve.



DN15-50 M1F, G1F & H1F

NUMBER 99.22.10-A Date: 08/09-2023

Maintenance



a. Remove actuator (and positioner if installed) following separate actuator instructions — Note: When the actuator is removed the valve will no longer be tight.

Pos.

1

2

3

4

5

6

7

8

Component

Stud bolt

Nut

Gasket

Gasket

Spring

Locking ring

Disc

Seat Cone

- b. Replace gaskets positions 3 & 4.
- c. Replace flange gaskets.
- d. Important note for position 4: A new gasket must be installed after each time the graphite gasket has been tightened and loosened again otherwise it will leak.
- e. Follow separate instructions for the actuator how to calibrate and install the actuator. If the actuator will not be mounted, it is possible to install a manual adjusting device in order to secure no external leakage from the valve

Important! Use Loctite for all screw connections that were disassembled.

Transport and storage

The valve must be transported and stored dry and clean. In humid rooms, a drying material or heating must be used to avoid condensation.

During transport and intermediate storage the valve should not be exposed to temperatures lower than -10°C. The valves are painted (top coated) on the outside. This coating must remain without damage, otherwise the faulty spots must be repaired immediately.

The standard packaging protects valves and equipment against rain and snow during trucking. For critical transports, such as sea freight, equipment will be protected by VCI (Volatile Corrosion Inhibitor) material. if protected by VCI do not remove the packing until the requirement is going to be installed






DN15-50 M1F, G1F & H1F

NUMBER 99.22.10-A Date: 08/09-2023

APPENDIX .Spare part manual

M1F SPARE PARTS

2-way Control Valves Cast iron, PN 16, DN 15/4-50 mm



S-2.3.02-A

Pos.	Component			
1	Stud bolt			
2	Nut			
3	Gasket			
4	Gasket			
5	Spring			
6	Disc			
7	Locking ring			
8	Seat			
9	Cone			

Order Information:

Packing set	Pos.	Valve	Item No.	Trim set	Pos.	Valve	Item No.	
pos.	1 to 4	15/4-15 M1F	1-2991209	components pos.	1 to 9	15/4 M1F	1-2991271	
	1 to 4	20/9-20 M1F	1-2991217		1 to 9	15/6 M1F	1-2991273	
	1 to 4	25/20-25 M1F	1-2991225		1 to 9	15/9 M1F	1-2991275	
	1 to 4	32/25-32 M1F	1-2991233			1 to 9	15/12 M1F	1-2991278
	1 to 4	40/32-40 M1F	0 M1F 1-2991241		1 to 9	15 M1F	1-2991281	
	1 to 4	50/40-50 M1F	1-2991263			1 to 9	20/9 M1F	1-2991284
					1 to 9	20 M1F	1-2991290	
					1 to 9	25 M1F	1-2991299	
					1 to 9	32 M1F	1-2991311	
					1 to 9	40 M1F	1-2991322	
					1 to 9	50 M1F	1-2991339	

3 of 6




mail@cloriuscontrols.com www.cloriuscontrols.com

DN15-50 M1F, G1F & H1F

NUMBER 99.22.10-A Date: 08/09-2023

G1F SPARE PARTS 2-way Control Valves Nodular cast iron, PN 25, DN 15/4-50 mm



S-2.5.02-A

Pos.	Component		
1	Stud bolt		
2	Nut		
3	Gasket		
4	Gasket		
5	Spring		
6	Disc		
7	Locking ring		
8	Seat		
9	Cone		

Order Information:

Packing set	Pos.	Valve	Item No.	Trim set	Pos.	Valve	Item No.
components pos.	1 to 4	15/4-15 G1F	1-2991209	components pos.	1 to 9	15/4 G1F	1-2991271
	1 to 4	20/9-20 G1F	1-2991217		1 to 9	15/6 G1F	1-2991273
	1 to 4	25/20-25 G1F	1-2991225		1 to 9	15/9 G1F	1-2991275
1 to 4	1 to 4	32/25-32 G1F	1-2991233		1 to 9	15/12 G1F	1-2991278
	1 to 4	40/32-40 G1F	1-2991245		1 to 9	15 G1F	1-2991281
	1 to 4	50/40-50 G1F	1-2991263		1 to 9	20/9 G1F	1-2991284
					1 to 9	20 G1F	1-2991290
					1 to 9	25 G1F	1-2991299
					1 to 9	32 G1F	1-2991311
					1 to 9	40 G1F	1-2991327

5 of 6




NUMBER 99.22.10-A

Date: 08/09-2023

DN15-50 M1F, G1F & H1F

H1F SPARE PARTS 2-way Control Valves Cast steel, PN 40, DN 15/4-50 mm



S-2.4.02-A

Pos.	Component				
1	Stud bolt				
2	Nut				
3	Gasket				
4	Gasket				
5	Spring				
6	Disc				
7	Locking ring				
8	Seat				
9	Cone				

Order Information:

Packing set	Pos.	Valve	Item No.	Trim set	Pos.	Valve	Item No.
components pos.	1 to 4	15/4-15 H1F	1-2991209	components pos.	1 to 9	15/4 H1F	1-2991271
	1 to 4	20/9-20 H1F	1-2991217		1 to 9	15/6 H1F	1-2991273
	1 to 4	25/20-2 <mark>5</mark> H1F	1-2991225		1 to 9	15/9 H1F	1-2991275
	1 to 4	32/25-32 H1F	1-2991238		1 to 9	15/12 H1F	1-2991278
	1 to 4	40/32-40 H1F	1-2991249		1 to 9	15 H1F	1-2991281
	1 to 4	50/40-50 H1F	1-2991268		1 to 9	20/9 H1F	1-2991284
					1 to 9	20 H1F	1-2991290
					1 to 9	25 H1F	1-2991299
					1 to 9	32H1F	1-2991314
					1 to 9	40 H1F	1-2991330
					1 to 9	50 H1F	1-2991341

6 of 6

